

Programming a New Continuous Infusion




1. Select "Standard Library"



2. Type "TP" When Prompted



3. Select "TPN"



4. Select Continuous



5. Enter Rate, Press "OK"



6. Enter Volume, Press "OK"